

RUBBER BOOT

P/N 8325858



- Use with X-am 3500 or X-am 8000 to add an extra layer of protection from drops and bumps.

